

TESTED TO COMPLY WITH



MEETS  
EN ISO:3059  
Specifications

# SPECTRO-UV®

## uVision™ 365 DELUXE SERIES



Also Avail-

Compliant, IP Rated, Fanless LED UV-A Lamps

UV-365HC + UV-365MHC

- ▶ Fully compliant to **ASTM E3022-18**
- ▶ Fanless design maintains optimum lamp temperature using state-of-the-art heat sinks
- ▶ For use in NDT applications including aerospace
- ▶ High-intensity UV-A beam for amazing fluorescent response
- ▶ Highest quality optics for superior light output



Compliant

**IP65  
RATED**



Dust Tight &  
Water Resistant



Fanless &  
Cool Running



Lightweight  
& Rugged



**3 UV-A LEDs**  
For wide area of coverage

Faceplate with  
**INTEGRAL UV-A  
PASS FILTERS**  
Reduces visible wavelengths

**ADJUSTABLE  
WHITE LIGHT LED**  
Use to locate surface  
flaws

**LONG-LASTING  
UV-A LENSES**  
Reduce the rate of  
solarization

**SEALED CONTROL  
SWITCH**  
Grip-mounted, three-  
way rocker switch  
(white light/off/UV)

**PISTOL GRIP**  
Comfortable,  
balanced control

**POWER/BATTERY  
LIFE LIGHT**  
Indicates power level

UV-365SBLC  
SPECTRONICS CORPORATION  
www.spectrolite.com

White Intensity

**BACK  
VIEW**




**WIDE, EVEN  
BEAM PROFILE**



**CERTIFICATE OF  
CONFORMANCE**  
included with each lamp


# uVision™ 365 DELUXE SERIES UV-365HC

MODEL	NOMINAL STEADY-STATE UV-A (365 nm) INTENSITY at 15 in (38 cm)	VISIBLE LIGHT MEASUREMENT	UV-A COVERAGE AREA at 15 in (38 cm) at minimum 1,000 $\mu\text{W}/\text{cm}^2$	AC/DC MOBILE VERSION
UV-365HC	6,000 $\mu\text{W}/\text{cm}^2$	< 1 foot-candle (11 lux)	7 in (17.8 cm) Diameter	
UV-365MHC	6,000 $\mu\text{W}/\text{cm}^2$	< 1 foot-candle (11 lux)	7 in (17.8 cm) Diameter	

- Light Source:** (3) UV-A LEDs, (1) white light LED
- Lamp Style:** Pistol grip
- Lamp Head Diameter:** 3.5 in (9 cm)
- Height:** 7.5 in (19 cm)
- Width:** 3.5 in (8.9 cm)
- Weight:** 1.9 lb (0.90 kg)
- White Light LED Intensity:** 400 foot-candles (4,306 lux)
- Power Requirements:** 100-120VAC / 12VDC  
(Also available in 230V & 240V versions)
- Battery Pack:** Type: 12V, NiMH (rechargeable)  
Run time: 3.5 hours continuous  
Charge time: 2 hours



CERTIFICATE OF CONFORMANCE



① UV-A intensity reading taken with the Spectro-UV® AccuMAX™ Series meter, and is factory set to the value shown.

\*Each lamp is fitted with an 8-foot cord and the appropriate plug for the country of destination. An optional 20-foot cord is available. The "/20" suffix denotes the 20-foot power cord options.

## uVision™ 365 AC DELUXE KIT

### UV-365HC

**Kit Includes:**  
Lamp with in-line AC power supply, UV-absorbing spectacles, comes in a protective case.






## uVision™ 365 AC/DC MOBILE DELUXE KIT

### UV-365MHC

**Kit Includes:**  
Lamp with in-line AC power supply, UV-absorbing spectacles, battery pack with 12V rechargeable NiMH battery, comes in a protective case.



## UV-A Beam Profile



DISTRIBUTED BY: